Gomanlift maintenance Interval

Version 02: 2611

Item	Action required	Before use	Intervals (hrs)						
			8	50	100	250	500	1000 /yr	2000
Decal & manual		●	●						
Engine air filter	Check	●							
	replace						●		
engine oil	Check fluid level	●	●						
	replace				●				
Engine belt	check							●	
coolant	Check & fill up	●	●						
fuel filter	Clean						●		
Hydraulic oil	Check & fill up	●							
	replace								●
hydraulic oil filter	Replace cartridge					●			
Worm gear	Check & grease			●					
Battery	Check liquid level				●				
Reducer gear oil	Check fluid level				●				
	replace			●				●	
Mechanical parts	inspection	●	●					●	
Arm/crawler extension pads	Check for wear	●				●			
	replace							●	
Turtable bolt tightening	Check					●			
Fastening bolts & screws	Check			●					
Fuel hose	replace								●
Turn table	grease							●	
Lithium battery	charge			●					
All the other grease nipples	grease			●					